

EG Configuration Center

programming manual for

EG BASICO
EG AVANCE
EG SUPERIOR

sequential gas injection controllers

ver. 4.8.0 dated 2017-08-31

welcome to
the WORLD
OF **automotive**

This instruction, diagrams and training movies can be also downloaded from:

www.europegas.pl/en/technical-support

EuropeGAS Sp. z o.o.

ul. Hurtowa 13, 15-399 Białystok, POLAND

tel.: +48 85 743 01 00

www.europegas.pl



export@europegas.pl



technical@europegas.pl



Table of content

1.First start of the program.....	4
1.1.Establishing connection with ECU.....	4
1.2.Standard mode.....	5
2.Main software window description.....	5
2.1.Petrol panel.....	6
2.1.1.Car settings.....	6
2.1.2.RPM Signal.....	7
2.2.Gas panel.....	8
2.2.1.Adaptation pressure parameters.....	8
2.2.2.Sensors.....	9
2.3.Changeover panel.....	10
2.3.1.To Gas.....	10
2.3.2.To Petrol.....	11
2.4.Calibration.....	12
2.4.1.Autocalibration.....	13
2.4.2.Petrol map.....	13
2.4.3.Gas map.....	13
2.4.4.Adjustments.....	13
2.4.5.Autoadaptation.....	14
2.5.RPM Map.....	14
2.6.Advanced.....	16
2.6.1.Injectors.....	16
2.6.1.1.Gas injectors.....	16
2.6.1.2.Petrol injectors.....	17
2.6.2.Corrections.....	18
2.6.2.1.Corrections.....	18
2.6.2.2.Enrichment.....	18
2.6.3.Advancement.....	19
2.6.4.Other.....	20
2.6.4.1.Cut-off.....	20
2.6.4.2.Hot start.....	21
2.6.4.3.Emergency start.....	21
2.6.4.4.Start and Stop.....	21
2.6.4.5.Petrol extra injection.....	21
2.6.4.6.Switch function.....	23
2.6.4.7.Fuel pump.....	23
2.6.4.8.Actuators testing.....	23
2.6.4.9.Cold VAG.....	24
2.7.OBD.....	25
2.7.1.Connection.....	25
2.7.2.Error codes.....	26
2.7.3.Banks.....	27
2.7.4.Corrections.....	27




2.8.Oscilloscope.....	29
2.9.Scan.....	31
2.10.Load test.....	31
2.11.Main menu bar.....	33
2.11.1.File.....	33
2.11.2.Edit.....	33
2.11.3.Language.....	33
2.11.4.Window.....	33
2.11.5.Options.....	34
2.11.6.Help.....	35
2.11.7.Toolbar.....	35
2.11.8.Wizard.....	36
2.11.9.Corrections.....	36
2.11.10.OBD.....	37
2.11.11.Emulators.....	37
2.11.12.TAP.....	38
2.11.12.1.Description of signal connections.....	38
2.11.12.2.Readings.....	39
2.11.12.3.Settings.....	40
2.11.12.4.Maps.....	41
2.11.12.5.Signals wave form.....	43
2.11.12.6.Service.....	44
2.11.13. Errors.....	45
2.11.14.Service Data.....	45
2.11.14.1.Working time.....	45
2.11.14.2.Settings modifications.....	46
2.11.14.3.ECU info.....	46
2.11.14.4.Inspections.....	46
2.11.14.5.Start emergency on gas.....	47
2.11.14.6.Password protection.....	47
2.11.14.7.ECU lock.....	47
2.11.15.Installation data.....	48
2.11.16.Nozzle.....	48
2.11.17.Help.....	49
2.11.18.Rate.....	49
2.11.19.Support.....	49
3.Usage of fuel changeover switch.....	50
4.Firmware update procedure.....	51
4.1. Firmware update procedure for AVANCE32, AVANCE48, SUPERIOR48.....	51
4.2. Firmware update procedure for BASICO24, BASICO32.....	51
4.3.Emergency firmware update procedure.....	52



1. First start of the program.

1.1. Establishing connection with ECU.




After first use of the software the window with question about default connection mode of establishing connection with ECU will appear.

"Turn on autoconnect" - if enabled will automatically search all available ports and try to establish connection with the controller automatically. If we choose "Yes" the software will try to automatically connect with ECU. If we choose "No" it will be necessary to choose the port manually from the list of available COM ports to establish connection with ECU.

If we will enable **"Don't show again"** the software will remember our choice for method of connection and will apply it during its every start. This settings can be changed any time in "Preferences" widow.

Connection with the controller can be also forced manually, by selecting appropriate COM port number from **"Port"** menu.

"Autoconnect" (shortcut key F5) -function is searching for a controller starting from the lowest COM number found in the system. Therefore it is recommended to assign the lowest possible COM port index for connected diagnostic interface to establish connection more quickly. We can always cancel Autoconnect procedure by selecting **"Disconnect"** and select COM port manually.



"Wifi" - If you select this option, the program will try to establish connection with ECU connected via the EG Connecto WIFI interface. Be aware that both the interface and the ECU should be powered when trying to establish connection. Also, check from the operating system level, whether you have connection with EG WIFI network. In case of problems, please verify way of connection according attached EG WIFI interface manual.



1.2. Standard mode

By choosing Standard mode we are starting traditional software interface containing all the options provided by the software for particular ECU.

- **Hint:** Software starts with standard set of options available by default. Some more advanced features are hidden. In order to show all the features available please go to: "Options->Preferences" and enable "Expert mode".

By default, immediately after starting the program, end-user will be asked to use the "Configuration Wizard". It simplifies the quick setting of gas ECU basic parameters without need to know the location of particular functions in the program bookmarks.

2. Main software window description



EG Configuration Center diagnostic software main window is composed of:

- Main menu bar located on the top of the window.
- Toolbar located below Main menu bar.
- Fuel type changeover switchboard visualization with fuel level indication diodes located in left top part of the window.
- List of active petrol/gas injectors with their injection opening times [ms] -middle top




part of the window.

- Visualization of actual system parameters -middle right side part of the window.
- Panels with system parameters/settings -central part of the window.
- System status indication and conditions bar -top right corner of the window.

Hint: Balloon tips with explanation are being displayed every time when mouse cursor is being held over particular function in software window.

2.1. Petrol panel



2.1.1. Car settings

- **Fuel type** -Select on what fuel type car is running ["LPG", "CNG"].
- **Number of cylinders** – Select number of cylinders in the car -[1...8] -according to amount of petrol/gas injectors connected.
- **Engine type** –Select the engine type ("Standard" or "Turbo") in order to have the correct value of manifold pressure (MAP) on the vertical axis on the map calibration .
- **Lambda type** –Set proper voltage type oxygen sensor characteristics.
- **Petrol injection type** –For cars having petrol injectors controlled by full group



strategy (all injectors controlled by single signal) or semi-sequential strategy (injector are being controlled by pairs) please change the "Petrol Injection type" from "Sequential" to "Full-group" or "Semi-sequential".

- **RPM type map** -Defines if in "Map" bookmark we can have possibility of modification of mixture composition by engine RPM [ms/RPM] or by value of absolute pressure inside intake manifold [kPa/RPM].
- **Constant MAP value**—This feature should be turned ON if the vehicle's engine type is having constant manifold absolute pressure value (eg. Valvetronic, Valvematic, MultiAir etc.). It is necessary to have OBD connection established to use that function. On the vertical axis of the map calibration in place of reading manifold pressure MAP will be the value of MAF . For cars that do not have air flow meter, select the " engine load " then appears on the load expressed in%.

2.1.2. RPM Signal

- **RPM signal source** -Defines the source of RPM signal. If brown RPM wire from the harness is connected to ignition coil, crankshaft position sensor or camshaft position sensor signal we need to select proper signal source. If brown wire is not connected (or not present) please choose "Injector", "OBD" or "TAP" (in case of EG SUPERIOR48).
- **RPM filter** —Filters the RPM signal to have smooth readout.
- **Rpm divisor** —Choose proper divider value to divide the RPM signal if the value read is not correct.
- **Autodetection** —Automatic detection of the RPM signal divisor and threshold.



2.2. Gas panel

- **Gas injector type** – Set proper gas injectors characteristics -[H2000/EG2000 type ABC 1,9 Ohm; H2100; EG2000 type A+ 1,3 Ohm; Keihin; BRC 1.9 Ohm; Rail IG1 3 Ohm; Rail IG5 3 Ohm; Magic Jet; Matrix; Matrix HD344/HD544; Rail IG3 Horizon 2 Ohm; Rail IG3 Horizon 2.8 Ohm; Reg OMLV Fast; Valtek 30 3 Ohm; Valtek 30/Rail IG1 2 Ohm; Valtek 30/Rail IG1 1 Ohm; Valtek 34; WGS 11/14/18/24; Tomasetto IT01; AEB INJ R4 I-Plus 2 Ohm; Barracuda; Tech Dragon; AC W01; AC W02; AC W03]
- **Gas injectors order** – By using this function we can reassign petrol injector emulators to any gas injector without changing physical connection. This functionality is useful when mistake during electrical connections has been made (petrol emulator is not matched with correct gas injector). We can also advance the gas injectors sequence using this box.
To activate this function we have to set "**Activation**" to "ON".

2.2.1. Adaptation pressure parameters

- **Minimum gas pressure** –Minimum gas pressure value required to cause changeover back to petrol. It is the lowest value of gas pressure at which the system allows to drive on gas. If the gas pressure value will fall below this value, for time longer than value set in "Pressure error time" the car will change over to gasoline from too low gas pressure.



- **Gas working pressure** –It is the normal value of gas pressure during last autocalibration on idle. “*Working gas pressure*” and “*Minimum gas pressure*” values are updated automatically during every autocalibration. In case of manual change of reducer's pressure these values must be updated every time.

Attention:

The system by default is making corrections of gas injection opening time according to working gas pressure value. Therefore it is necessary to have working gas pressure parameter value in the software agreeing to real value of gas pressure in the system.

2.2.2. Sensors

- **Pressure sensor type / Reducer temperature sensor / Gas pressure sensor type-** in case of using a Pressure sensor / Vacuum sensor / Reducer temperature sensor or/and Gas temperature sensor different from standard ones (***ABS400kPa*** and ***4.7kOhm*** type sensors, which are provided with the ECU set and selected as default configuration) please change sensor type in a proper field.
- **Level sensor type** – select proper type LPG level sensor (default is 0-5V Hall) or CNG pressure gauge (default is 0-5V Hall) installed. If it is necessary to adjust original standard sensor characteristics of level sensor press ***"Set min"*** when gas tank is empty and ***"Set max"*** when gas tank is full. We can restore default values anytime by clicking ***"Default"*** button.
LED activation threshold values can be also modified manually by moving the sliders by clicking and dragging them with mouse cursor.



2.3. Changeover panel

2.3.1. To Gas

- **Reducer temperature** -Minimum value of reducer temperature required for opening the solenoid valves before first changeover to gas.
- **RPM changeover level** -Minimum value of RPM level to first changeover to gas.
- **Changeover time -cold engine** -Minimum value of time period from the moment of opening solenoid valves to the opening of first gas injector on cold engine.
- **Changeover time -hot engine** – Minimum value of time period from the moment of opening solenoid valves to the opening of first gas injector on hot engine.
- **Changeover delay per cylinder** -Time delay between turning on/off subsequent gas injectors during changeover from petrol to gas.
- **Sound when changeover to gas** -If turned "ON" buzzer gives sound during every switchover between from petrol to gas.
- **Show time to changeover** -After engine start, the amount of time remaining to switchover from petrol to gas is being showed on the fuel switch diodes. As the reducer temperature rises, the more LEDs on the fuel switch are being light up. When system is switched to gas, the LEDs display the current gas level in the tank.




- **Fuel overlapping cycles** – enables simultaneous injection of the gas together with gasoline during changeover to gas. It is adjustable by setting desired number of overlapping cycles. It eliminates the feeling of transition to gas using long gas pipes.

2.3.2. To Petrol

- **Minimum RPM** -Minimum value of RPM level required for changeover back to petrol when car runs on gas. If actual RPM value is lower than this value the car will immediately changeover to gasoline mode. When the RPM value will go back above this value the car will go back to gas mode.
- **Maximum RPM** -Maximum value of RPM level required for changeover back to petrol when car runs on gas. If actual RPM value is higher than this value the car will immediately changeover to gasoline mode. When the RPM value will go back below this value the car will go back to gas mode.
- **Max load value** -Maximum value of petrol injection opening time at which car can still run on gas. If petrol injection time value will be higher than this value the car will changeover to gasoline mode. When the value of petrol injection time will fall back below this value the car will go back to gas mode.
- **Maximum load on the engine** - the function of switching the engine on gasoline based on calculated by the load controller. If the injection timing loop, and we're not sure of the mixture at high loads can be set, for example. 85 %, which switches the engine on petrol.
- **Pressure error time** -Time period during which the gas pressure could be lower than the "*Minimum pressure*" value. If the pressure will drop and stay below this value for time longer than this time period the car will change over to gasoline from too low gas pressure.
- **Minimum gas temperature** -Minimum value of gas temperature required for changeover back to petrol. If gas temperature will fall below that value during driving on gas the system will go back to gasoline mode and will not allow to go back to gas mode until the gas temperature will be greater than this value.
- **Sequential back to petrol** -Feature enables sequential switchover from gas to petrol with the `time delay between subsequent cylinders as set in "*Changeover delay per cylinder*".
- **Hide temporary back on petrol** -If turned "*OFF*", the LPG/CNG diode blinks during temporary switchover to gasoline.
- **Don't inject petrol** -delay of petrol injectors activation for defined number of cycles during changeover to petrol. It allows you to reduce the effect of "flooding" the engine during changeover from gas to petrol due to too long gas pipes.



2.4. Calibration



Map In "**Calibration**" bookmark is showing dependency of petrol injectors opening time [ms] on petrol (red points) and petrol injectors opening time on gas (blue points) related to value of manifold absolute pressure (vacuum) in the engine inlet manifold [kPa]. On the right side of Calibration bookmark there are indication of petrol (red colour) and gas map (blue colour) buffers [%].

Colour marker on the intersection of horizontal and vertical dashed lines shows the actual values of MAP and petrol injectors opening time.

Left vertical axis is reserved for Multiplier line values (blue horizontal line with point on each millisecond) which is being used for adjustment of gas injection opening time for all gas injectors.

The point of multiplier can be marked by clicking left mouse button and dragged up or down by moving mouse cursor while holding left mouse button. Multiplier points can be also modified by following keyboard shortcuts:

- ← -left arrow -Changes active point to previous one by 1 ms.
- → -right arrow -Changes active point to next one by 1 ms.



- ↓ -bottom arrow -Decreases the multiplier for particular petrol injection opening time. In example changing the multiplier value from 1,0 to 0,8 will cause shortening of gas injection opening time by 20%.
- ↑ -upper arrow -Increases the multiplier for particular petrol injection opening time. In example changing the multiplier value from 1,0 to 1,2 will cause elongation of gas injection opening time by 20%.
- Page Up –Moves the whole multiplier line up by 0,1.
- Page Down -Moves the whole multiplier line up by 0,1.

The active multiplier point can be automatically shifted along with the actual petrol injection time. In order to modify successfully the multiplier points without using the arrows ←, → please activate the **"Adjustment Assistant"**.

2.4.1. Autocalibration

- **Autocalibration start** – Starts the procedure of automatic calibration on idle.
- **Correction** –Shows common additive correction for all gas injectors.
- **Injection time** –Saved petrol injection time on idle during last autocalibration.
- **Simultaneous changeover all cylinders during autocalibration** –It's used to changeover all gas injectors simultaneously during autocalibration first changeover to gas.

2.4.2. Petrol map

- **Petrol Map continuous mode** –In this mode petrol map is continuously collected even when petrol map buffer is full.
- **Erase petrol map** –This button enables to erase petrol map.
- **Erase button lock**– This mode protects petrol map from accidental erasing by clicking „Erase petrol map“ button.

2.4.3. Gas map

- **Gas map continuous mode** -In this mode gas map is continuously collected even when gas map buffer is full.
- **Erase petrol map** –This button allows to erase gas map.

2.4.4. Adjustments


- **Calculate adjustments** -Calculates multiplier correction based on the petrol and gas maps deviation.
- **Erase adjustments** –This button enables to clear all the multiplier adjustments. (Restores the value of 1.0 for all points of the line multiplier).



2.4.5. Autoadaptation

- **Autoadaptation** -Makes possible to enable (ON) or disable (OFF) the autoadaptation feature. Autoadaptation calculates multiplier adjustments in case if petrol and gas maps are getting more distant from each other during the drive.
- **Max. change** –Defines the value of maximum change of each multiplier point during autoadaptation step.
- **Period [min]** -Defines length of time interval after which the software will do another multiplier adjustments calculation.

2.5. RPM Map




In this bookmark it is possible to adjust the composition of air/fuel mixture in specific ranges of petrol injection opening time <0...27 ms> depending on RPM level <0...8000 RPM>. These thresholds may be adjusted by clicking and dragging the line section at the height of the *ms* or *RPM* label.

Thanks to that map we can adjust mixture by shortening or elongating the gas injectors opening time in range from -50% up to +50%. RPM value on the map can be changed by drag and drop.



Editing of the cells on the map can be done in following way:

- By clicking and holding left mouse button we are marking the area on which we would like to enter the desired percentage correction of gas injectors opening time.
- By clicking on any of cells in area marked by us with right mouse button.
- Pop-up menu will show up, with following list of options available to apply to selected cells:
 - "Clear all"** -Sets cells to the 0 value.
 - "Increase 1%"** -Increases cell value by 1%.
 - "Increase 5%"** -Increases cell value by 5%.
 - "Increases 5 %"** -Decreases cell value by 5%.
 - "Decrease 5%"** -Decreases cell value by 5%.
 - **"Set value"** -Opens window with list of values to choose from range -50% up to +50%.



After selecting cells on the map it is also possible to modify their value on active map area with usage of following numerical keys:

- **"Page Up"** –Increases value by 5%.
- **"Page Down"** –Decreases value by 5%.
- **"+"** -Increases value by 1%.
- **"-"** -Decreases value by 1%.
- **"Delete"** -sets value to 0%.



2.6. Advanced

2.6.1. Injectors

The screenshot displays the EG Configuration Center software interface. At the top, there is a menu bar with options: File, Edit, Port, Language, Window, Options, Help. Below the menu is a toolbar with icons for Wizard, Corrections, OBD, Emulators, Errors, Service, Nozzle, Help, Rate, and Support. The main area shows a row of eight injectors, each with a green checkmark and numerical values (5.4 and 8.3). Below this, there are tabs for Petrol Panel, Gas Panel, Changeover, Calibration, Map, Advanced, OBD, Oscilloscope, Scan, Load Test, and Debug. The 'Advanced' tab is selected, showing settings for Gas injectors, Petrol injectors, and Fuel pressure dropping. On the right side, there is a 'CONNECTED' status panel with 'Conditions' (Solenoid valves open) and 'Readings' (Petrol OFF, Gas ON, RPM 1997, Gas press. 0.99, MAP 0.58, Reducer temp. 64, Gas temp. 43, Petrol time 5.39, Gas time 8.34, Engine load 8, Power supply 11.78, Lambda 1 1.21, Lambda 2 0.86). At the bottom right, there is an 'OBD status' panel with a red warning icon.

2.6.1.1. Gas injectors

- **Gas injectors warming up** –If we will enable this feature by setting to ON we can set period of time for which the gas injectors coils should be electrically preheated, before first changeover to gas, by single pulses from ECU (properly shortened so they won't cause opening of injector) before first changeover to gas. Function works if the reducer temperature is not higher than "Hot engine temperature".
- **Gas injectors testing** –When this feature is enabled controller is checking the continuity of ECU and gas injector circuit. When the harness plug will loose contact or the coil will get damaged the system will automatically go back to petrol and signalize the error e.g. "Gas injector 1 not connected".
- **Minimum injector opening time** –This parameter forces the gas injectors be opened for opening time period not shorter that set value. If calculated injection opening time would be shorter than this value, the injectors are going to be opened for defined amount of time.



- **Remember off state gas injectors** –When this function is on software remembers turned off gas injectors during every next engine start.
- **Built-in injectors characteristic** –This function introduces the predefined characteristics of selected gas injectors which, in case of proper components selection and assembling, eliminates necessity of doing multiplier corrections calculation.

2.6.1.2. Petrol injectors

- **Ignoring the petrol opening signal below** –This parameter sets the minimum threshold below which the petrol injectors opening time will be not read and not converted to gas injection opening time. This option should be enabled when petrol injection controller generates very short pulses on petrol injectors (from 0,3 [ms] up to 1,1 [ms]), which normally doesn't cause dosage of petrol fuel but after summation with all controllers corrections (e.g. additive, multiplier and map correction etc.) might cause unwanted gas injection. Default value "0.0" means that every pulse from petrol injector will be moved onto gas injectors.

Attention: We shouldn't use that function unless that petrol injectors short pulses causes performance problems during driving on gas.

- **Dropping the fuel pressure** -controller sequentially switches single cylinders from gas to petrol supply so that the pressure on the fuel rail remained constant. We set the pressure at idle on petrol basing on OBD readout, then we switchover the gas. We should set % of fuel that won't allow petrol pressure does not grow while working on gas. The time we set the drop so that did not feel like fuel switching.



2.6.2. Corrections

2.6.2.1. Corrections

The screenshot displays the EG Configuration Center software interface. The main workspace shows eight injectors with their respective status indicators. The 'Corrections' tab is active, showing settings for Gas working pressure (1.00 [bar]), Gas working temperature (38 [C]), and Reducer working temperature (50 [C]). The right-hand panel shows engine readings including RPM (1997), Gas pressure (0.99 bar), MAP (0.58 bar), Reducer temp (64 C), Gas temp (43 C), Petrol time (5.38 ms), Gas time (8.33 ms), Engine load (8%), Power supply (11.78 V), Lambda 1 (1.21), and Lambda 2 (0.86). The interface also includes a menu bar (File, Edit, Port, Language, Window, Options, Help) and a toolbar with icons for Wizard, Corrections, OBD, Emulators, Errors, Service, Nozzle, Help, Rate, and Support.

- **Gas working pressure** –Stored value of gas pressure during last autocalibration on idle. Correction will be applied to calculated gas injection times when the pressure will increase above or decrease below this value
- **Gas working temperature** –Correction will be applied to calculated gas injection times when the gas temperature will increase above or decrease below this value
- **Reducer working temperature** –Correction will be applied to calculated gas injection times when the reducer's temperature will increase above or decrease below this value

2.6.2.2. Enrichment

- **First changeover enrichment/leaning** -Enables to enrich or lean the mixture after first changeover (on cold engine). After activating this feature it is possible to lean/enrich the mixture once after first changeover from petrol to gas. After first changeover to gas the gas injection opening time will be elongated/shortened by selected enrichment level (in %). During desired enrichment time (in sec.) the enrichment/leaning value will be decreasing/increasing down to 0%.



Attention: Function works when the reducer temperature is lower than "Hot engine temp." and only after first changeover to gas from the moment of engine start.

- **Emergency start on gas enrichment/leaning** –Enables to additionally enrich or lean the mixture after emergency start on gas.
- **Acceleration enrichment/leaning** –Turn on/off extra enrichment of gas mixture only during rapid accelerations. We can define how much the mixture will be enriched during rapid acceleration by increasing value of "Strength of extra enrichment". As higher the that value is, as more powerful and longer the enrichment will be.
- **Mazda leaning** –Automatically detects change of petrol injection strategy from sequential to semi-sequential and it's shortening gas injection time according to Mazda leaning percentage [%] value during all the period of work in semi-sequential mode.

2.6.3. Advancement

The screenshot displays the EG Configuration Center software interface, version 4.8.0. The main window is titled "EG Configuration Center ver 4.8.0" and features a menu bar (File, Edit, Port, Language, Window, Options, Help) and a toolbar with icons for Wizard, Corrections, OBD, Emulators, Errors, Service, Nozzle, Help, Rate, and Support. The central area shows a visual representation of eight injectors, each with a green checkmark and a numerical value (5.5 or 8.5). Below this, there are three panels: "1: Petrol Panel", "2: Gas Panel", and "3: Changeover". The "Advancement" tab is selected, showing options for "Number of advancement cycles" (set to OFF) and a "Preview" checkbox. The "Banks" section allows for cylinder assignment to Bank 1 or Bank 2. The "Petrol injectors order" section shows a "Scan order" sequence: 1 → 8 → 7 → 3 → 6 → 5 → 4 → 2. The right-hand side of the interface is a "CONNECTED" status panel with a "Conditions" section (Solenoid valves open) and a "Readings" section. The readings include: Petrol (OFF), Gas (ON), RPM (1997), Gas press. [bar] (0.99), MAP [bar] (0.58), Reducer temp. [C] (64), Gas temp. [C] (43), Petrol time [ms] (5.49), Gas time [ms] (8.47), Engine load [%] (8), Power supply [V] (11.78), Lambda 1 [V] (1.21), and Lambda 2 [V] (0.86). A "Rich" to "Lean" scale is visible below the lambda readings. The "OBD status" section at the bottom right shows a red shopping cart icon.

- **Banks** -Allows each cylinder to be assigned to the appropriate bank ("V" type engines). The correct assignment of cylinders with banks is very important for



proper operation of the injection angle advancement as it should take place within one bank.

- **Petrol Injectors Order** -"Scan order" button activates ignition sequence scanning, so the ECU detects the ignition order of the mixture on each cylinder and displays it in the software.
- **Advancement** -When the system is powered by CNG, there may be uneven motor performance or power drop in some engine loads range due to the different physical properties of CNG compared to gasoline. In order to optimize the engine's performance during work on gas fuel, this feature allows to advance the injection angle by 180 °, 360 °, or 540 °.
- **Preview** -selecting this option displays a matrix showing which petrol injectors controls particular gas injectors.

2.6.4. Other

The screenshot shows the EG Configuration Center software interface. The main window displays a dashboard with various engine parameters and configuration options. The top bar shows the software version (EG Configuration Center ver 4.8.0) and a menu (File, Edit, Port, Language, Window, Options, Help). Below the menu is a toolbar with icons for Wizard, Corrections, OBD, Emulators, Errors, Service, Nozzle, Help, Rate, and Support. The main area is divided into several sections: 1. Petrol Panel (showing 8 injectors with values like 17.3, 15.1, 15.0, etc.), 2. Gas Panel, and 3. Changeover. Below these are tabs for Calibration, Map, Advanced, OBD, Oscilloscope, Scan, Load Test, and Debug. The 'Other' tab is selected, showing configuration options for Cut-off, Hot start, Emergency start, Start and Stop, Petrol extra injection, Fuel pump, Actuators testing, and Cold VAG. The right sidebar shows 'CONNECTED' status and a list of readings including RPM (4304), Gas press. (0.99), MAP (0.94), Reducer temp. (64), Gas temp. (43), Petrol time (17.30), Gas time (15.06), Engine load (98), Power supply (11.80), Extra Petrol Inj. (2.6), and Petrol Time Equiv. (14.5). It also shows Lambda 1 (1.21) and Lambda 2 (0.86) readings, and Bank 1 AFR (0.0), Correction (0.0), STFT, LTFT, O2S1, and O2S2 readings. The OBD status is shown at the bottom right.

2.6.4.1. Cut-off

- **Leaning after Cut-off** –This function helps in reducing the gas pressure overgrowth effect.
- **Cut-off pressure** –Defines the value of threshold above which gas pressure is considered as too high and mixture leaning process will be activated.
- **Leaning cycles** –Use of this feature can lean the mixture when gas pressure



would exceed "*Cut-off pressure*" for defined amount of subsequent gas injection cycles which length shall be reduced.

- **Leaning range** –Percentage of reducing gas injection opening time when gas pressure would exceed "*Cut-off pressure*" value.

2.6.4.2. Hot start

- **Hot start enabled** –Activates Hot Start function. When engine is hot the car starts directly on gas (without usage of petrol).
- **Hot engine temperature** –Defines temperature threshold of reducer temperature above which hot start is possible.
- **Hot start enrichment** –Activates function of enrichment/leaning during hot start. Function increases or reduces gas injection opening time for short time period after hot start.
- **Hot start enrichment level** –Defines percentage value of shortening / elongating gas injection opening time when hot start enrichment works <-50% ... +50%>.

2.6.4.3. Emergency start

- **Remember start on gas** –Remembers the state of emergency start on gas and repeats it without need of holding switch button pressed during every next engine start.

2.6.4.4. Start and Stop

- **Start and Stop system** –Function which should be activated for a regular continuous work on gas for vehicles equipped with Start and Stop system.

2.6.4.5. Petrol extra injection

- **Protection of valve seats** – Adds small amount of gasoline during gas injection, in order to protect the valve seats and valves. Gasoline injectors will be opened for 3.5 ms every time when RPM will exceed 3500 and gasoline injection will be longer than 8 ms. Gas injection time will be shortened accordingly to keep the stoichiometric mixture ratio.
- **Compensate weak reducer** – function can be use as temporary solution when reducer or injectors are getting close to their efficiency limit. Gasoline injectors will be opened for 3.5 ms every time when RPM will exceed 3500 and gasoline injection will be longer than 8 ms. Gas injection time will not be shortened so the mixture will be more rich. When this feature is active we should adjust the multiplier lines above 8 ms so that the air-fuel mixture ratio when extra injection is active will be correct.
- **Others** -User can determine at what working conditions gasoline extra injection should be present. By enabling function "**Don't shorten gas injection time**" the ECU will not be shortening the gas injection pulse while dosing extra-injection of



gasoline. This way it can compensate weak regulator or weak injectors in the higher range of engine loads. When that function is set to off to **"OFF"** the gas injection times will be shortened in such proportion which will allow to keep the air-fuel mixture stoichiometric.

Extra petrol injection settings

Enable petrol extra injection: ON

Don't shorten gas injection time: OFF

RPM activation level:

- Low RPM level: 0 - 3500 [RPM]
- Medium RPM level: 3500 - 4500 [RPM]
- High RPM level: 4500 - 8000 [RPM]


Petrol injection time activation:

- Low RPM level: 8.0 [ms]
- Medium RPM level: 8.0 [ms]
- High RPM level: 8.0 [ms]

Extra petrol injection time:

- Low RPM level: 0.0 [ms]
- Medium RPM level: 3.0 [ms]
- High RPM level: 3.0 [ms]

To fine-tune the vehicle in the areas in which petrol extra injections are active we use the "Map" tab, where these areas are graphically highlighted by appropriate colors. Colors of selected areas are corresponding to the colors in the "Extra petrol Injection Settings" tab at user-defined ranges of RPM and injection times.



To properly tune the mixture composition when petrol extra injection function is activated, the EPT (equivalent petrol time) marker is used. The EPT Marker is visible as an orange dot on RPM map. The actual position of EPT marker on the map shows at which injection times enrichment value need to be changed in order to change the composition of the mixture while petrol extra-injection is active.



2.6.4.6. Switch function


- **Long switch button function** –Additional function which can be activated by long pressing (5 sec.) of switch button. Following functions can be assigned:
 - **calculate multiplier** -Calculates multiplier basing on deviation of both collected maps.
 - **system tuning** -Starts autocalibration process, erases petrol and gas maps, calculates multiplier after recollecting 100% of both maps. Then it enables autoadaptation process.
 - **gas level setting** -Registers the minimum level in the tank, and after filling the gas, registers the maximum level and divides the thresholds automatically.
 - **none** –No action is assigned to this function.

2.6.4.7. Fuel pump

- **Fuel pump state** –Defines how the fuel pump deactivation works. Following methods are available:
 - **Always ON** –Fuel pump always works on both fuels,
 - **Always OFF** -Fuel pump is always disconnected and doesn't work on both fuels,
 - **Delay OFF** –Fuel pump becomes disconnected after programmed time delay.
- **Switch-off delay** -Programmable time delay after which fuel pump becomes disconnected. It is being counted from the moment of turning on all gas injectors.

Attention: Disconnecting the fuel pump must be done in accordance with the wiring diagram.

2.6.4.8. Actuators testing





The feature set included in this block function allows for component diagnostics and safe operation when servicing the gas system.

ATTENTION!: The actuators tests can be started only when the gas ECU is powered on and the engine is not running.

- **Switch test** -Allows to diagnose the functionality of the fuel selector switch. When the test is run, the LEDs light up and the buzzer sounds.
- **Fuel Pump Test** -Allows You to manually turn off and turn on the fuel pump. If the ECU has these functions, "GND" signal will appear on the pink ECU harness for shutting off the fuel pump.
- **Injectors ActivationTests** -Starts the selected gas injector, allowing you to locate it or check if it is defective.

WARNING! To prevent the engine from being flooded with gas, the function can only be activated after the "Gas draining" procedure.

- **Drain System** -Procedure of emptying the gas system for service and diagnostics purposes. Instruction displayed by the program, are showing step by step how to drain the gas system from gas on whole circuit between the tank multivalve to the gas injector hoses.
- **Tightness test** -Opens the solenoid valves on the tank and on the pressure regulator and fills up the gas system. Once the conditions in the system have been stabilized, the gas pressure is measured for period of 120 seconds. After this time, the current pressure value is compared with the value from beginning of the measurement. If the pressure difference is greater than 30 kPa, a gas leakage warning message will be displayed.
- **Open the solenoid valves** -Opens the solenoid valves in order to verify if they operate properly.

2.6.4.9. Cold VAG

The feature set included in this functionalallows for component diagnostics and safe operation when servicing the gas system.



2.7. OBD

2.7.1. Connection

The screenshot displays the EG Configuration Center software interface. At the top, there is a menu bar with options: File, Edit, Port, Language, Window, Options, Help. Below the menu is a toolbar with icons for Wizard, Corrections, OBD, Emulators, Errors, Service, Nozzle, Help, Rate, and Support. The main area is divided into several panels:

- Top Panel:** Shows eight cylinders with their respective fuel and air flow readings. Fuel flow is 17.2 for all cylinders, and air flow is 14.8 for cylinders 1-5 and 14.9 for cylinders 6-8.
- Left Panel:** Contains the 'Connection Wizard' section with a status of 'INITIALIZED'. It includes options for 'OBD connection' (ON) and 'Protocol' (CAN 250k 11b). Below this are 'Error codes' settings, including 'Auto erase all error codes' and 'Auto erase OBD errors'. At the bottom of this panel are buttons for 'Read error codes' and 'Erase error codes'.
- Center Panel:** Shows 'ECU address' settings, 'Type of addressing' (Physical), and 'Find ECUs' button. It also includes 'Banks' (Cyl 1-8) and 'Corrections' settings such as 'OBD corrections' (OFF), 'Correction type' (Normal), 'Correction speed' (Slow), and 'Idle rpm' (1000).
- Right Panel:** Titled 'CONNECTED', it shows 'Conditions' (Petrol extra injection, Solenoid valves open) and 'Readings' for various parameters: Petrol (ON), Gas (ON), RPM (4304), Gas press. [bar] (1.00), MAP [bar] (0.94), Reducer temp. [C] (64), Gas temp. [C] (43), Petrol time [ms] (17.20), Gas time [ms] (14.81), Engine load [%] (98), Power supply [V] (11.80), Lambda 1 [V] (1.21), and Lambda 2 [V] (0.86). It also shows 'Bank 1' readings: AFR (0.0), Correction (0.0), STFT (-), LTFT (-), O2S1 (-), and O2S2 (-). The 'OBD status' is shown as a yellow icon.

It is strongly recommended to click on the “**Connection Wizard**” button to establish connection with OBD smoothly. Connection Wizard is a tutorial which helpful in carrying out all the necessary actions needed to have connection with petrol ECU (eg. initialize connection, find OBD protocol, get ECU address, select PIDs to be read by gas ECU).

We can also perform all mentioned tasks manually using buttons located on the top-left side of OBD bookmark.


- **OBD connection wizard** -Starts tutorial which guides user step by step through the OBD configuration process.
- **OBD status** -Shows the current status of the connection to the OBD system.
- **OBD connection** – Makes available to set OBD connection to *OFF*, *ON* or *AUTO* (when car is started on Petrol Mode, the gas ECU is automatically releasing OBD line).
- **Protocols** -Enables to select type of protocol in accordance with connection made. There are following protocols available one the list:
 - K-line protocols*: ISO14230/KWP-2000 SLOW; ISO14230/KWP-2000 FAST;



ISO9141; ISO9141-2.

-*OBD CAN protocols*: CAN-250kb-11bit; CAN-250kb-29bit; CAN-500kb-11bit; CAN-500kb-29bit.

- **Find protocols**-Searches automatically for type of OBD protocol supported by a car.
- **Type of addressing** –Select the correct type of addressing used in car: *logical* or *physical*.
- **Find ECUs** – Automatically searches for all available ECUs. Search results are displayed below along with ECUs addresses. The numbers in parentheses indicate the number of processes in the ECU at the moment. When there is more than one ECU we should try to select the ECU with the greatest number of processes.



Attention:

Frequency of refreshing the OBD parameters values is depending on amount of parameters selected for reading. When we want to use OBD corrections it is recommended to leave only Long Time Fuel Trims 1 [%] (and Long Time Fuel Trims 2 [%] in case of having 2 banks) parameter selected for quicker update of these parameters.

2.7.2. Error codes

- **Read error codes** -Reads Stored and Pending error codes from the OBD with the description of each code.
- **Erase error codes** -Erases stored error codes from the OBD. In some particular cases for successful erasing of OBD error codes we need to do it when the engine is off, and +12V from the key is being given to the controller (ACC position of the



key).


- **Auto erase fuel trim error codes** -Erase fuel trim error codes each time before starting the engine.
- **Auto erase all error codes** -Erase all error codes each time before starting the engine.

Attention: Enabling options "Auto erase fuel trim error codes" and "Auto erase all error codes" may cause engine damage. Turn this option on at your own risk.

2.7.3. Banks

Banks -The concept of banks is referring to "V" type engines. Cylinder marked as no. 1 should be always in bank no. 1. "V" type engines should always have one side assigned to bank no. 1 (cylinders with numbers from 1 to 3 in V6 engines or from 1 to 4 in V8 engines) and another side to bank no. 2 (cylinders with numbers from 4 to 6 in V6 engines or from 5 to 8 in V8 engines). To assign cylinders , start the engine and wait until the ECU connects to the OBD . The engine should work at idle and then perform the following procedure for all cylinders starting at 1 :

- in the " **Corrections** " disable "**change for all**" and doubling the corrections for the first cylinders
- to observe which of the two " Banks " STFT They go in the direction of the rich
- after finding why the " Banks " change STFT assign the injector to the corresponding " Bank "
- we change the correction value to the initial and repeat the entire procedure for all cylinders



2.7.4. Corrections

System reads the *Long Time Fuel Trim (LTFT)* values from vehicle's OBD and dynamically changes the amount of gas injected in a way which helps the LTFT to oscillate close to expected car's manufacturers default value (so called *Neutral point*": It is possible to set different neutral points for idling and higher revs conditions.

In example: if LTFT value keeps going in positive direction (increasing), it means that




mixture is too lean and gas ECU is increasing the gas injection opening time to enrich the mixture. Finally the LTFT are going in negative direction (decreasing). The introduced OBD corrections comes back to 0 value when when LTFT value is reaching *Neutral Point*.

- **OBD corrections** – Makes possible to enable (*ON*) or disable (*OFF*) the OBD corrections feature.
- **Correction type** -Set proper corrections type:
 - **Normal** -When air-fuel mixture goes lean the LTFT correction value increases,
 - **Reverse** -When air-fuel mixture goes lean the LTFT correction value decreases,
 - **Fiat** -For specific corrections used in Fiat brand vehicles.
- **Correction speed** -Speed of introduced OBD correction should be chosen adequately to speed of vehicle LTFT changes. We can set this parameter to *Slow* or *Fast* value.
- **Idle RPM** –Defines idling threshold above which vehicle's OBD changes its target LTFT neutral point.
- **Neutral point [%]** -Default vehicle's OBD value of LTFT parameter when engine is working on petrol in closed loop mode.
- **Neutral point on idle [%]** -Default vehicle's OBD value of LTFT parameter when engine is working on idle revolutions on petrol in closed loop mode.
- **Max. correction [%]** -Defines the limit of maximum OBD correction that can be introduced into gas injectors opening time.
- **Max. correction on idle [%]** -Defines the limit of maximum OBD correction that can be introduced into gas injectors opening time on idling.

Actual value of calculated OBD correction should be checked from time to time. Too big value of that correction mean that some mechanical part might be worn out and we should make some mechanical adjustments to some parts of sequential gas injection system.



2.8. Oscilloscope



Oscilloscope shows run of selected ECU signals. On the right side of main window we can select (by marking a tick) which ECU signals we would like to see on oscilloscope run. We can also visualize required OBD readouts by selecting them from OBD icon located on the left side of the Toolbar.


On the bottom right side of oscilloscope window we can find buttons to: change the units displayed on the right vertical axis (**C**, **kPa**, **V**, **RPM**, **ms** etc.).

On the bottom part of oscilloscope bookmark there are following buttons available (starting from the left side):

- **Record** -Starts recording and displaying selected signal values.
- **Preview** -Enables to preview and displays values of recorded signals in time moment selected by cursor.
- **Replay** -Plays recorded oscilloscope run in real time from the time moment selected by cursor.
- **Stop** -Stops recording and displaying oscilloscope run. We can rewind and check value of recorded signals anytime.
- **New** -Clears all recorded or loaded oscilloscope data from the screen.




- **Open from file** -Loads the oscilloscope run from "osc" file for preview.
- **Save to file** -Saves recorded oscilloscope run to "osc" file for further use.
- **Insert marker** -writes a marker on the of the oscilloscope to make it easier to find the marked occurrence in its timeline. It is also possible to describe the comment tag. You can also insert a tag by double-clicking with the left mouse button on the oscilloscope timeline.





2.9. Scan



Petrol and gas injection oscilloscope scanner is a tool useful for diagnostic purposes. With use of this scanner it is possible check: the order of the injection sequence, injectors overlapping occurrence, presence of shorts injection pre-pulses etc.

To perform scanning procedure please click "**Scan (F4)**" button while being in *Scan* bookmark or press **F4 key** anytime from any bookmark in the software.

Screenshot with actual waveform from all injectors injection signals will appear on the screen. The red waveform refers to petrol injection and the blue waveform refers to gas injection on each cylinder.

2.10. Load test

Implemented Load Test module allows to measure the power and torque of the vehicle's engine during test drive.

All power and torque measurements, which are going to be compared between each other, needs to be done on the flat, straight road in the same driving conditions.

First we need to open "**Car data**" window and enter all the vehicles parameters. If any parameters will be not corresponding to the real data the result of the measurements also won't be reliable.



We should select gear 3rd and accelerate to speed which should be entered as **"Reference speed [km/h]"** and keep that speed constant. The engine RPM level reached while we are maintaining that speed should be entered as **"Reference RPM"**. After fixing these values we can lower the speed.

In **"Begin RPM"** field we should enter RPM value from which measurement will be started. In **"End RPM"** field we should select RPM value, after exceeding which, measurement will be finished.

The measurement should be made on the same gear on which "Reference RPM" has been set (gear 3rd is recommended).


The RPM value in the moment of starting the measurement should be lower than "Begin RPM" value. We are starting the measurement by pressing **"Start 1"** button. We have to press the acceleration pedal to the maximum and hold it until we exceed "End RPM" value. The testing procedure will end automatically and the results will be displayed on the chart. By moving the cursor horizontally on the chart we can read and compare the values between each measurement results.

It is possible to save and hold in the ECU memory results of three measurements.



2.11. Main menu bar

2.11.1. File



- **Save settings** –Saves ECU settings to file.
- **Load settings** -Loads settings from saved file to ECU.
- **View settings** -Enabling to preview previously saved settings.
- **Restore to default** -Restores default manufacturer's settings.
- **Firmware update** -Updates firmware of gas ECU.
- **TAP -update firmware** –Updates firmware of Timing Advance Processor module (if present).
- **Exit** –Ends work with software.

2.11.2. Edit

- **Undo** –Cancels last action which has been done in the software. It is possible to undo up to last 20 actions made.
- **Redo** –Repeats last action made which has been undone in the software.

2.11.3. Language


This option allows to change displayed software's language.

2.11.4. Window

Enables to select following features from the list instead of using the Toolbar: Wizard, Corrections, OBD, Emulators, TAP, Errors, Service, Nozzle.



2.11.5. Options



Here we can define our preferences regarding software behavior and appearance.

- **Show options at program start** -During each start of the software shows window with Mode selection and Autoconnect option.
- **Auto connect at program start** – Defines if program should establish connection with gas ECU automatically during every software start or not.
- **Auto record oscilloscope at program start** -Software automatically starts recording Oscilloscope signals during every start.
- **Show toolbar icons** –Toolbar icons can be visible or hidden.
- **Show toolbar labels** –Toolbar labels can be visible or hidden.
- **Ask to save settings before closing the software** -reminds about saving



setting to file before close software.

- **Ask to save oscilloscope file before closing the software** --reminds about saving oscilloscope to file before close software.
- **Check for newer firmware version when connecting with ECU** --Software is automatically checking if ECU contains newest firmware version and offers possibility of possible upgrade.
- **Pressure unit** -Type of pressure units displayed in the software: KPa, bar or psi.
- **Temperature unit** -Type of temperature units displayed in the software: Celsius or Fahrenheit.
- **Speed unit** -Type of speed units displayed in the software: kilometers per hour or miles per hour.
- **Expert mode** -Software is showing its all Extra-Advanced features.
- **Program color** -Changes main program window colour and layout.
- **WiFi connection enabled** -Allows to establish connection via dedicated WiFi diagnostic interface and displays connection settings.
- **Check for updates at program start** -Software is automatically checking available updates during every start (active Internet connection required).
- **Send statistics of software usage** -Allows to send the anonymous statistic to the manufacturer for product development purposes.
- **Check for updates now** -Forces software to automatically check available updates (active Internet connection required).
- **User settings directory** -Defines path for keeping saved files.

2.11.6. Help


- **Documentation** -Opens folder with user manual and wiring diagrams.
- **Shortcuts** -Shows list of available keyboard shortcuts.
- **Rate software** -Gives possibility to rate the software and send the issued assessment to manufacturer.
- **About us** -Shows information with manufacturer's contact data.

2.11.7. Toolbar






2.11.8. Wizard



Starts Configuration Wizard. It's a tutorial helpful in carrying out all the necessary actions needed for quick configuration of freshly installed system.

2.11.9. Corrections




Shows additive corrections window. Value of this correction [ms] is being added to petrol injection opening time when car is on gas. That value is being set by software automatically during autocalibration process.

When **"Change for all"** is ON then by modifying Correction #1 we can change that value for all remaining cylinders.




2.11.10. OBD



Shows window containing all available OBD readings and enables to choose the parameters for be read from OBD and to be visualized on the oscilloscope run.


2.11.11. Emulators



Shows petrol injectors emulators diagnostic window. It is possible to close and open petrol injection emulation circuit for diagnostic purposes.



2.11.12. TAP



Shows interface and bookmarks related to configuration of built-in EG Dynamic Timing Advance Processor module.

To correct configuration we need to properly diagnose and connect the crankshaft position sensor and the camshaft position sensor (if present), are located. First, we set the sensor type:

- if the connector have two pins, it is an **inductive sensor type** (resistance value for a typical inductive sensor is approximately 1 kOhm)
- if connector has three-pins, it can be **inductive sensor type**(two pins sensor, the third pin ground. The resistance between the two pins of the sensor is approximately 1 kOhm, and the third pin from the ECU is connected to the ground)
- if connector has three-pins, it can be **digital sensor type** (ground, power supply, signal). One pin from the ECU is connected to ground, the other is power "+12V from the ignition key", the third one is a signal cable)

2.11.12.1. Description of signal connections

TPS signal:

Signal of Throttle position sensor or acceleration pedal sensor. Connecting that signal is required for proper calibration and detection of idle and cut-off conditions. TPS signal wire is the one on which voltage (regarding the ground) changes its value fluently (eg. from 0 to 5V) when we are pressing on the accelerator pedal when vehicle's ignition key is on.

Crankshaft position sensor signals:

Main and most important signal to connect is the crankshaft position sensor signal. Camshaft position sensor signal don't have to be connected if it is not necessary to do so. This kind of necessity might happen when the original ECM of the car is report errors related with not synchronizing the camshaft position signal while advancing the signal from crankshaft position sensor. At first we should identify the type of sensor. Inductive



sensor -usually it has pins which goes to two lines covered by a screen. Resistance measured between these two lines is around 1000 Ohm. If there are three pins, two of them are connected to signal lines and third one is connected with screen which is the ground signal of vehicle's ECU.

Hint if possible we should find the place to cut into signal wires at where additional cover/screen insulation of signal wires is not present. First we should identify two signal wires, cut them and make serial connection by connecting proper pairs of wires from TAP device.

There are four wires used to cut into vehicle's inductive signal wires: yellow and white -channel A, green and brown -channel B. We should start with cutting only one signal wire at a time (let's name it 'signal wire A') and connect first pair of inductive signal wires from TAP device:

- yellow wire -should be connected with vehicle's inductive signal wire A input going from the inductive sensor
- white wire -should be connected with vehicle's inductive signal wire A output going to the petrol ECU Then we proceed with cutting second signal wire (let's name it 'signal wire B') and connect remaining pair of inductive signal wires from TAP device:
- green wire -should be connected with vehicle's inductive signal wire B input going from the inductive sensor
- brown wire -should be connected with vehicle's inductive signal wire B output going to the petrol ECU

Attention: If above connections will be made improperly we may be not possible to start the vehicle.

Camshaft position sensor:

Digital sensor. Usually that kind of sensor have three lines signal, ground, power supply: +5V or +12V signal. We should cut only the signal wire and connect it serial to digital channel pair of wires.

Hint: The original wire of signal input from digital sensor should be always connected to the color wire with black stripe (blue- black or yellow-black color). The adequate color wire without stripe should always be connected to that part of original vehicle's sensor signal wire which goes to the petrol ECU (blue or yellow color). Otherwise it might cause problem with engine work

2.11.12.2. Readings

On the right panel we have actual value of all TAP working parameters:

- **Shifting** –This value is informing if the impulses are being advanced or delayed (ON) or not (OFF) at the present moment.
- **Gas** –This value is signaling on what fuel the car the car is actually running: on gas (ON) or petrol (OFF).
- **Angle [`]** -Angle value (in degrees) by which the current revolutions signal is being



shifted.

- **RPM** –Rotary engine speed value.
- **TPS [%]** –Position of throttle position or accelerator pedal.
- **MAP [kPa]** –Actual value of the absolute pressure in the intake manifold.
- **Inductive [Hz]** -Current frequency of pulses for a signal from the inductive sensor.
- **Digital 1 [Hz]** -Current frequency of pulses for a digital sensor signal no. 1
- **Digital 2 [Hz]** -Current frequency of pulses for a digital sensor signal no. 2
- **Power supply [V]** -Power supply value. This value shouldn't be lower than 9V and not higher than 15V.

Conditions window located on the bottom right side of TAP window shows if any of TAP parameters is out of allowed working range or some signal is not read properly. It determines if ignition signal shifting can be done or not. E.g. we will receive proper message when the car is not in gas mode or the TPS signal is below minimum value programmed to start ignition shifting.


2.11.12.3. Settings

- **TPS Calibration** -Calibration of the minimum and maximum TPS input voltages for fully released and for maximally pressed accelerator pedal.
- **Enabling configuration** -Defines ranges in which TPS and RPM actual values must be inside with in order to shift ignition signal. Shifting can be set to: *automatic (default value), always enabled or always disabled.*
- **Advanced**
 - **Pressure sensor type** -Selects the type MAP sensor connected (default value is *ABS400kPa*).
 - **TPS acceleration correction** -The choice of TPS signal changes sensitivity. It's helpful in cases at which original ignition signal angle temporary increases significantly when accelerating. This allows to temporary increase the angle of signal shifting by extra value for the rapid accelerations to compensate this signal change. It works only when RPM value is less than 1500 RPM.
Attention: Default value of this parameter is "0". It is not recommended to increase value of that parameter if it is not necessary.
 - **Allowed retard** –Allows shifting signal to have negative value. The ignition will be retarded instead of advanced. Default setting is OFF. Use this option only for conversion of CNG dedicated vehicles to LPG. Otherwise the vehicle engine may get damaged.
- **Acceleration test** -Automatically measures **Acceleration time [s]**. This time period is measured from the moment of reaching **RPM begin** value to the moment of reaching **RPM end** value.
- **Inductive sensor, Digital sensor 1, Digital sensor 2**
 - **Connections** -Type of sensor to which signal input has been connected.
 - **Impulses per 1 revolution** -Number of pulses per revolution detected during





- o a scan run (control value).
- o **Scan** –Starts automatic scanning of the sensor signal wave. Should be carried out under stable conditions when the engine is running on idle. It is necessary to provide the actual value of engine rotary speed before starting scanning.

Attention: It is very important to always start scanning from the crankshaft sensor signal, and proceed to scanning of the camshaft sensors signals (if they have been connected).



2.11.12.4. Maps







Map of the angle shifting regarding engine rotary speed.

Point of the violet line indicates the current signal pulses shifting offset (in degrees).

It is recommended to set a lower angle value at higher rotary speeds.



Multiplier Correction (eg. 1.0 is 100%, 0.6 is 60% of original shifting offset) of the angle regarding the engine manifold absolute pressure (engine load). For heavy loads is recommended to set the adjustment below 1.0 to do not increase the engine knock value.



Multiplier Correction (eg. 1.0 is 100%, 0.6 is 60% of original shifting offset) of the angle regarding the TPS signal value.

For idle conditions signal pulses shifting should be disabled, because it can lead to engines RPM waving in some type of vehicles. We can do it by lowering the multiplier line on the map or in the Settings panel.


Allowed shortcuts and controls for map modification:

- *Pressing left mouse button and dragging* -Move the points in the X and Y axis.
- *Pressing right mouse button and dragging* -Move only points in Y axis.
- *Double clicking left mouse button* -Add or remove point.
- *Arrow left, arrow right* - selection of point.



- *Shift + arrow left, Shift + arrow right* -Selection of a group of points.
- *Ctrl + A* – selection of all the points.
- *Arrow up, Arrow down* -Moving points in the Y-axis.
- *Home, End* -Moving points in the Y-axis with a higher speed.
- *Ctrl + arrow up, Ctrl + down, Ctrl + left, Ctrl + right* -Moves points in the X and Y.
- *Insert* -Adds another point.
- *Delete* -Removes the selected point.
- *Page Up, Page Down* -Moves the whole multiplier line in the Y-axis.

2.11.12.5. Signals wave form



In this bookmark we can preview the shape of each scanned sensor signal wave.



2.11.12.6. Service

The screenshot shows the 'Service' tab of the TAP EG-Dynamic application. It is divided into three main sections: Device information, Advanced readings, and a Readings list.

Device information:

- Firmware version: 1.7.1
- Compilation time: 2015-03-20 09:09:16 UTC
- Serial number: 8709374048556750066BFF57

Advanced readings:

- Show advanced readings
- Inductive sensor:** Noise count 0, Desync count 0, Signal Vpp 0.8
- Digital sensor 1:** Noise count 0, Desync count 0
- Digital sensor 2:** Noise count 0, Desync count 0
- Temperature: 40.1

Readings:

Reading	Status/Value
Shifting	OFF
Gas	ON
<input checked="" type="checkbox"/> Angle [°]	0.0
<input checked="" type="checkbox"/> RPM	0
<input type="checkbox"/> TPS [%]	0
<input checked="" type="checkbox"/> MAP [bar]	0.91
<input type="checkbox"/> Inductive [Hz]	0
<input checked="" type="checkbox"/> Digital 1 [Hz]	0
<input checked="" type="checkbox"/> Digital 2 [Hz]	0
<input checked="" type="checkbox"/> Power supply [V]	11.6
<input type="checkbox"/> Debug 1	42.5
<input type="checkbox"/> Debug 2	35.9

Conditions:

- Channel2 signal error
- RPM out of range

This bookmark Device information and Advanced readings helpful in diagnostic purposes.



2.11.13. Errors

Total working time	80h 40m
ECU run time	12m 7s
Gas temp. [C]	484
Reducer temp. [C]	484
Gas press. [kPa]	0
MAP [kPa]	0
Lambda 1 [V]	0.0
Gas time [ms]	0.0
Petrol time [ms]	0.0
Power supply [V]	0.0
RPM	0

On the list we can find gas ECU Pending errors (black colour) and Stored errors (red colour). We can choose which errors must cause changeover to petrol and which mustn't (they will be only registered in ECU memory).

When error is being registered in the ECU memory it automatically contains Freeze Frame with all system data saved when error occurred.

It is also possible to set continuous signal for errors (buzzer will be beeping continuously until switch button will be pressed).

2.11.14. Service Data

In Service Data bookmark we can find useful information about ECU.

2.11.14.1. Working time

We can check for how long time period ECU was working **on petrol**, **on gas** and the both fuels **total** time. These three parameters are being automatically measured from the time of installation and can not be modified by end-user. **Gas filter working time** and **Gas injector working time** shows the time elapsed from moment of changing filters or injectors. We may clear these times by the pressing **clear** button. **Injector cycles on/off** counts gas injector opening cycles.



The screenshot shows a 'Service data' window with a blue header and a close button. It contains several sections:

- Report options:** A 'Generate PDF report' button.
- Service Data / Installation Data:** Two tabs, with 'Service Data' selected.
- Working time:** A list of metrics: On petrol (70h 10m), On gas (378h 21m), Total (448h 31m), Gas filter working time (380h 45m), Gas injector working time (0h 00m 00s), and Injector cycles on/off (0). Each has a 'Clear' button.
- Settings modifications:** Last modification date (2017-09-01), Last modification service code (6F0E-DC54), and Service code of this station (6F0E-DC54).
- ECU info:** Type (AVANCE 32), Firmware version (5.15), Serial number (1615-00006), and ID number (2094).
- Inspection:** Time left for next inspection (10h 00m), Set inspection after (500 km), and a 'Set' button. A note states: 'Calculated time assumes average speed 50km/h'.
- Start emergency on gas:** Number of start on gas (0) and Limitation of start on gas (4).
- Password protection:** Protection state (Disabled), New password, Confirm Password, Preview protection (checked), and buttons for Sign In, Set, and Clear.
- ECU lock:** Time left for ECU lock (indicated by a dashed line) and Set ECU lock after (Disabled) h, with a 'Set' button.

2.11.14.2. Settings modifications

Last modification date and **last modification service code** informs us when recently they ECU settings was modified and gives the PC service code which was used. Service code of this station is a unique computer code which we used to connection at the moment.

2.11.14.3. ECU info

Informs us which **Firmware version** is currently inside ECU and what is the type of this ECU. **Serial number** is a unique number assigned for this ECU. ID number is used for ECU model **identification**.

2.11.14.4. Inspections

- **Time left for next inspection** -Displays amount of time [hh:mm] left for the next service inspection.
- **Set inspections after** -Here we can set amount of kilometers left to drive before the service inspection will be signaled. We assume that 1 hour of system work is equal to driving 50 km.

Service time is being signaled by the buzzer only when "Total working time" value will exceed the value set in "Set inspections after" field. In such case, after every start of the car in Auto mode, the buzzer will sound for a short period of time, yellow diode will blink few times and car will automatically go back to Petrol mode. In such case we need to press button to go back to Auto mode every time when we want to drive on gas unless we will disable it or set another Service inspection.



2.11.14.5. Start emergency on gas

Number of start on gas -Shows how many times car owner is allowed to use emergency start of gas function. It is possible to set **limitation of start on gas** which may prevent from abusing of this feature by car owner.

2.11.14.6. Password protection

It is possible to prevent unauthorized end-users from changing ECUs settings by setting supervisor password. Password must be exactly 8 characters long and should contain only alphanumerical chars [A...Z, a...z, 0..9].

When supervisor password has been set then, after every try of establishing connection with ECU, software will ask user to enter password. Without giving valid password the access to configuration panels will be locked. User will be allowed to preview actual systems parameters, oscilloscope readings and data from Service bookmark but he won't be allowed to change any controllers data. **Preview protection feature** additionally prevents previewing the actual system parameters.

Password can be deactivated any time by using **Clear** button.

2.11.14.7. ECU lock

After exceeding programmed working time the ECU doesn't allow car owner to drive on gas until he will go to authorized service station to unlock the ECU.



2.11.15. Installation data

Service data

Report options

Service Data **Installation Data**

Car model: Audi A4
Car engine: 1.8 T 110KW AEB
Car mileage: 21339 km
Car VIN: WAUZZXCZ23213213XZ
Nozzles: 2.2
Auto service: Ksiezyno
Owner: Jan Kowalski
Contact: +48857430120

Assembly date: 2017 9 1 Today is **2017-09-01**

Warranty by: 24 months **730 days left**

Credit date: 2017 12 5 **95 days left**

Other

This bookmarks allows to store in ECU memory most important information about vehicle, vehicle owner, technical data, ECU installation date, remaining warranty period and other useful information.

2.11.16. Nozzle

Injectors calculator

Parameters

Fuel type: LPG
Number of cylinders: 4
Power [HP]: 100
Injection type: Sequential

Nozzle diameter

1.8 mm

Hana injectors

For pressure under max load [bar]: 1.00

Recommended injector type

TYPE C or **GOLD 1,9 Ohm**



Injectors nozzle calculator helps installer to choose appropriate type of injector and injector nozzle. Algorithm assumes that reducer's differential pressure has been set at 1 bar (for LPG reducer) or 1,8 bar (for CNG reducer).

We need to be aware that calculated values are only approximate values and it is strongly recommended to start drilling the injector nozzles from a little smaller diameter from calculated one by 0,2 mm.

2.11.17. Help

Opens folder with user manual and wiring diagrams.

2.11.18. Rate

Gives possibility to rate the software and send the issued assessment to manufacturer.

2.11.19. Support

Downloads and start software which will allow to have remote session with EG Technical Support Department.



3. Usage of fuel changeover switch



Fuel changeover switch consists of:

- **Fuel changeover button** -Located in the center part of the switch. every single press of the button changes the type of selected fuel.
- **Gas mode LED** (yellow colour) -Located in the bottom right part of the switch. It shows current status of working on gas or waiting for changeover to gas.
- **Petrol mode LED** (green colour) -Located in the bottom left part of the switch. It shows current status of working on petrol.
- **Fuel state LED-s** -4 green LED-s and 1 red LED indicating gas reserve -located at the left side of the switch. 4 green LED-s shows amount of fuel level left in the gas tank. If all 4 green LED-s are ON simultaneously and red LED is OFF then the tank is full. If all 4 green LED-s are turned off and the red LED is ON, it means that the gas tank is almost empty.

Switch LED-s can indicate following states:

- Gas mode LED is OFF, Petrol mode LED is ON, the fuel state diodes of the diodes are all OFF -system is in Petrol mode.
- Gas mode LED is blinking once per second, Petrol mode LED is ON, the fuel state LED-s are ON -system awaits for reaching min. reducer temperature and other conditions required for changeover.
- Gas mode LED and Petrol mode LED are blinking alternately, the fuel state LED-s are OFF there are two possibilities:
 - system is signaling a malfunction (eg. too low gas pressure value), which is causing instant changeover to Petrol mode. The buzzer sound will be also present during this occurrence.
 - autocalibration process is running.
- Gas mode LED is ON, Petrol mode LED is OFF, the fuel state LED-s are ON -system is in Gas mode.

The system should be normally started on petrol and after reaching programmed conditions it should automatically changeover to gas. However it is possible to force an emergency start of gas -without usage of petrol (eg. when the petrol fuel pump has been damaged). To force emergency start on gas we should:

1. Press and hold the switch button before starting the engine.
2. Move the ignition key to ACC position,
3. Wait for opening of solenoid valve,
4. start the engine on gas,
5. release the switch button.



4. Firmware update procedure

For proper firmware update procedure the +12V ignition key wire from gas ECU harness needs to be connected to the place in which +12V voltage appears from the moment of turning on the ignition key to ACC position, do not drops below +9V during engine cranking and remains stable during all the time of engine's work. Voltage should drop to 0V shortly after turning off the ignition key.

4.1. Firmware update procedure for AVANCE32, AVANCE48, SUPERIOR48.

It is recommended to run firmware update procedure when engine is not running and ignition key is on.

ATTENTION: Don't loose the +12V from the key or don't try to disconnect diagnostic interface during firmware update process or as it might interrupt the communication between gas ECU controller and PC. In result controller can get damaged in a way that is not covered by the warranty repair.

1. We are turning on the ignition key to give +12V to the controller.
2. After successfully establishing connection with the diagnostic software we should choose from main menu: **File -> Update Firmware.**
3. We should select file with newest version of firmware file for our controller. After successful validation of firmware file we will be asked confirmation of update process from our side. We should confirm by clicking "Yes" button.
4. Present gas ECU configuration will be saved in settings file and update process will be started. On progress bar displayed on the screen we can observe update progress.
5. After finishing updating process message with information that firmware has been updated successfully will appear. We need to confirm it by pressing OK. It is not necessary to turn off and turn on power supply of the controller.

4.2. Firmware update procedure for BASICO24, BASICO32.


1. For BASICO line controllers, start the engine first to connect to the software via the diagnostic interface,
2. Start the software and after connecting, select from the main menu: **File -> Update Firmware.**
3. We should select file with newest version of firmware file for our controller. After successful validation of firmware file we will be asked confirmation of update process from our side. We should confirm by clicking "Yes" button
4. Present gas ECU configuration will be saved in settings file and update process will be started. On progress bar displayed on the screen we can observe update progress.
5. When the update process reaches about 15%, turn off the engine and do not start it until the update process is complete.
6. When the update process is completed, a window will appear telling you that the firmware has been updated successfully. We need to confirm by pressing the OK button.




4.3. Emergency firmware update procedure

In case of standard method of firmware update will fail we should proceed with emergency firmware update procedure:

1. Disconnect with the controller and turn off the ignition key. Status in top right part of software window should be "Disconnected" and all LED-s on the switch should be OFF.
2. Select proper COM port on which diagnostic interface is present.
3. Choose from main menu **File -> Upload Firmware** and select firmware that You want to use for updating the ECU.
4. Follow the instructions displayed by the program (ECU power must be switched on 10 seconds from the moment when information window will appear).



5. When power will applied to the ECU on time, the firmware update progress bar will appear.



Attention: In the BASICO line controllers there is no physical connection with +12V ACC (igniton key signal), so ECU detects moment of turning the engine off by using the other engine parameters. When the interface is connected to the BASICO driver, the connection will be active all that time when the engine is shut down, allowing you to finish update process successfully.